

SCRUBMASTER 210

INTRODUCTION

OPERATING & MAINTENANCE INSTRUCTIONS

READ THIS BOOK

This operator's book has important information for the use and safe operation of this machine. **Read this book carefully before starting the machine.** Keep this book and tell all operators to read the book. If you do not follow the instructions, you can cause an injury or damage equipment, furniture or buildings.

For new books write to:

Pacific
2259 S. Sheridan
Muskegon, MI 49442-6252

Carefully inspect all components to ensure that there is no concealed freight damage. If such damage is discovered, file a "CONCEALED DAMAGE REPORT" immediately with the delivering carrier.

The contents of this manual are based on the latest product information available at the time of publication. Pacific Steamex reserves the right to make changes or improvements to its machines without notice.

FOR YOUR CONVENIENCE, RECORD THE FOLLOWING IMPORTANT INFORMATION:

MODEL _____

SERIAL NUMBER _____

PART NUMBER _____

DATE PURCHASED _____

TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	3
SYMBOLS USED ON THE MACHINE	5
MACHINE PREPARATION	6
1. UNPACKING THE MACHINE	
2. BATTERY INSTALLATION	
3. CONNECTING THE BATTERY CHARGER	7
4. CHARGING THE BATTERIES	
5. CONNECTING THE BATTERY CONNECTOR	8
6. BATTERY CHARGE LEVEL INDICATOR	
7. SQUEEGEE ASSEMBLY	
8. ADJUSTING THE SQUEEGEE HEIGHT	
9. ADJUSTING THE SQUEEGEE INCLINATION	9
10. INSTALLING THE SPLASH GUARD	
11. BRUSH INSTALLATION	
12. RECOVERY TANK	10
13. SOLUTION WATER	
OPERATION	11
OPERATING	
DEVICE TOO FULL	12
MOVEMENT	
UPON COMPLETION OF THE WORK	13
DAILY MAINTENANCE	14
CLEANING THE RECOVERY TANK	
CLEANING THE VACUUM FILTER	
CLEANING THE SQUEEGEE	
REPLACING THE SQUEEGEE BLADES	15
DISASSEMBLY OF THE BRUSH	
WEEKLY MAINTENANCE	16
CLEANING THE SQUEEGEE HOSE	
SOLUTION TANK CLEANING	
TROUBLE SHOOTING GUIDE	17
INSUFFICIENT WATER ONTO THE BRUSH	
THE MACHINE DOES NOT CLEAN SATISFACTORILY	
THE SQUEEGEE DOES NOT DRY THE FLOOR WELL	
EXCESSIVE FOAM PRODUCTION	
WARRANTY POLICY	18

IMPORTANT SAFETY INSTRUCTIONS


READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS BEFORE OPERATING THIS MACHINE!




WARNING: To reduce the risk of fire, electric shock or injury:

1. You must have training in the operation of the machine before using it. **READ THE INSTRUCTION BOOK.** If you do not understand any instruction, ask your supervisor.
2. Make sure all labels, decals, warnings, cautions and instructions are fastened to the machine.
3. Read the labels carefully on the machine. Do not cover them for any reason and replace them if damaged.
4. Do not operate this machine unless it is completely assembled, inspect the machine carefully before operation.
5. Pay close attention to other people and especially children while operating this machine.
6. Be a careful driver, do not strike shelving or scaffolding, especially where there is a danger of falling objects.
7. Machines can cause an explosion when operated near flammable materials and vapors. Do not use this machine with or near fuels, grain dust, solvents, thinners, or other flammable materials.
8. In case of fire, use a powder extinguisher. Do not use water.
9. Do not use this machine as a means of transport.
10. Do not use acid solutions that could damage the machine.
11. Adjust your speed to the conditions of the floor.
12. Do not turn the machine on a ramp. Do not stop and leave the machine on a ramp or incline.
13. When the machine is parked, take out the key and set the parking brake.
14. During any maintenance operation disconnect the power supply from the machine.
15. Lead acid batteries generate gases that can cause an explosion. Read the instruction manual supplied with the battery charger. Keep sparks and flames away from batteries.
NO SMOKING. Charge the batteries only in an area with good ventilation.
16. Do not use a charger if the power cord is damaged.
17. Always wear eye protection and protective clothing when working near batteries. Remove all jewelry. Do not put tools or other metal across the battery terminals, or the tops of the batteries.
18. Check the level of the electrolyte every time you charge the batteries. If the level is low, add distilled water only.
19. Maintenance and repairs must be performed by authorized Service Centers only. Make adjustments according to the specifications given in the service manual for this machine.
20. Keep the electrical parts of the machine dry. Do not wash the machine with direct water jets or high pressure, nor with corrosive material. For storage, keep the machine in a dry building.
21. Water solutions or cleaning materials used with this type of machine can leave wet areas on the floor surface. These areas can cause a dangerous condition for the operator or other persons. Always put CAUTION signs near the area you are cleaning.
22. Do not reach under shrouds with fingers, hands, or toes when machine is running.


SYMBOLS USED ON THE MACHINE




Symbol for the **water level**:
Indicates the valve is open.




Symbol indicating the raised or lowered position of the **brush base**:
Indicates the lever for lifting the brush base.




Symbol for the **brush**:
Indicates the brush motor switch.




Symbol for the **vacuum motor**:
Indicates the vacuum motor switch.




Symbol indicating the raised or lowered position of the **squeegee**:
Indicates the squeegee lever position.



Symbol indicating the charge levels of the **batteries**:
It is necessary to recharge the batteries when the green light begins to blink



Indicates the **drain hose** of the recovery tank.



Indication of the maximum recommended temperature for the solution water (50°C or 122°F): It is located near the fill hole of the solution tank.




Symbol for the **coupling**:
Indicates the anchor points and the load direction.


MACHINE PREPARATION

1. UNPACKING THE MACHINE

1. Use a fork truck to move the machine when packaged.
2. Take off the outer package
3. The machine is fixed on the pallet with wooden wedges that block the wheels.
4. Take the wedges off.




5. Using a ramp, pull the machine down from the pallet, pushing it in reverse motion. Avoid violent blows to the base.




2. BATTERY INSTALLATION

The two 12 volt batteries fit in the compartment under the recovery tank.

 For battery maintenance and charging, follow the instructions provided by the battery supplier.


Installation Instructions:

1. Lift the recovery tank forward.
2. Detach the squeegee hose (1) from the recovery tank.
3. Take off the vacuum plug (2) by rotating it counterclockwise.
4. Remove the drain hose from its' hook and take the recovery tank off.




MACHINE PREPARATION

5. Place the batteries in their compartment.
6. Connect the batteries' connector (2) to the machine's connector (1).
7. Reassemble the recovery tank, vacuum plug and squeegee hose.



3. CONNECTING THE BATTERY CHARGER

The battery charger's connector fits into the battery connector (2) located under the recovery tank.



4. CHARGING THE BATTERIES

Make sure the battery charger is for use with the installed battery, both capacity and type (lead/acid or GEL).



WARNING! NEVER CHARGE A GEL BATTERY WITH AN INCORRECT BATTERY CHARGER.

NEVER ALLOW THE BATTERIES TO RUN COMPLETELY DOWN, recharge them within a few minutes after the battery indicator starts blinking. **Never leave the batteries completely discharged**, even if the machine is not being used.



WARNING! When charging the batteries, follow all the instructions provided with this manual and the battery charger. Trained staff must carry out the installation and maintenance operations.



WARNING! Fire Danger: Lead acid batteries generate gases that can cause an explosion. Keep sparks and flames away from batteries. **NO SMOKING!**



WARNING! To prevent an explosion, charge the batteries only in an area with good ventilation.



WARNING! Always wear eye protection and protective clothing when working near batteries.


When charging the batteries, keep the recovery tank lifted with the prop as shown in the figure.

Turn the key to the OFF position. Connect the DC connector on the charger to the DC battery connector. Connect the AC charger plug to a receptacle that has the correct voltage and frequency for your charger. Make sure the receptacle is connected to the electrical ground.

MACHINE PREPARATION

5. CONNECTING THE BATTERY CONNECTOR

After charging the batteries, reconnect the battery connector (2) to the connector of the machine (1).




6. BATTERY CHARGE LEVEL INDICATOR

The batteries' indicator is digital with 4 fixed positions and a blinking one. The numbers, which appear on the display, show the approximate charge level.


4 = maximum charge, **3** = charge 3/4, **2** = charge 2/4, **1** = charge 1/4,
0 = (blinking) discharged batteries)

NOTE: The brush motor automatically switches off a few seconds after the battery indicator light begins to blink. By restarting the machine, you will be allowed to turn on the vacuum motor and finish drying any wet areas.



7. SQUEEGEE ASSEMBLY


The squeegee is assembled as shown in the figure. The squeegee lever should be in its up position. Insert the holding pin into the squeegee stud bolt to secure the squeegee in place. Then fit the squeegee hose into its coupling; the hose should be located to the right of the lifting cable.



8. ADJUSTING THE SQUEEGEE HEIGHT

The height from the floor to the squeegee should be adjusted based on the blade's wear. Rotate the wing nuts (1) counter-clockwise to lift the squeegee and clockwise to lower it.


Note: Adjust the right and left wing nuts the same amount; the squeegee should be positioned parallel to the floor.



MACHINE PREPARATION


9. ADJUSTING THE SQUEEGEE INCLINATION

During operation, the rear squeegee blade is most efficient when tilted back about 3/16 inch (5mm) along its whole length. To increase the blade bending in the central part, tilt the squeegee body backward by turning the adjuster counter-clockwise. Subsequently, turn the adjuster clockwise to increase the bending at the sides of the squeegee blade.




10. INSTALLING THE SPLASH GUARD

The splash guard should be installed as shown in the picture.




11. BRUSH INSTALLATION

1. Lift the brush base with the foot pedal.




2. Place the brushes under the base. Line up the lugs with the holes in the brush plate. Insert the brushes into the plate and turn each brush so the lugs are pushed toward their retaining springs, until locked in place.

The picture shows the direction of rotation for the right brush. The left brush is rotated in the opposite direction.



MACHINE PREPARATION


3. Invert the positions of the right and left brushes daily. However, if the brushes are not new and have deformed bristles, it is better to reassemble them in the same position. Because the different inclination of the bristles may cause an overload to the brush motor and excessive vibrations.



12. RECOVERY TANK

Open the lid and confirm the following connections are secure:

1. The vacuum plug (2) is securely attached, turn clockwise to tighten.
2. The vacuum hose (1) is attached.
3. The plug on the drain hose (on the back of the machine) is inserted.




13. SOLUTION WATER

Fill the solution tank with clean water at a temperature not more than 50°C/122°F. Add the proper concentration of liquid detergent by following the manufacturer instructions. Excess foam in the recovery tank can damage the vacuum motor, so use only the minimum amount of detergent necessary. Reassemble the cover.




WARNING!: Always use low foaming detergent. Adding antifoam liquid into the recovery tank before cleaning will also help prevent foaming. **NEVER USE PUREACID.**




OPERATION

OPERATING


1. Connect the machine connector (1) to the battery connector.




2. Press the brush motor switch (2).
3. Press the vacuum motor switch (3).



4. Adjust the amount of cleaning solution through the lever (4). There should be enough solution to wet the floor uniformly, but not so much that it gets past the splash guard. Remember that the correct solution quantity depends on the type of floor, the dirt and the speed.
5. Release the pedal and lower the brush base.
6. Lower the squeegee using lever (5).



7. The brushes start turning by pressing on the lever (6). During the first few yards of operation, check that the quantity of the cleaning solution is sufficient and that the squeegee dries the floor surface.




OPERATION

DEVICE TOO FULL

The machine is equipped with a float that stops the vacuum when the recovery tank is full. When this occurs, empty the recovery tank by removing the plug on the drain hose.



WARNING! Use gloves for protection from contact with dangerous solutions.



MOVEMENT

The movement of this machine is obtained through brush assistance.

There is no separate traction drive motor in this unit.





WARNING! Lift the squeegee when moving backward.

UPON COMPLETION OF THE WORK

After finishing your work and before any type of maintenance is done, it is necessary to do the following:

1. Close the water valve through lever (1).
2. Raise the brush base with the pedal.
3. Lift the squeegee with lever (2). Note: The squeegee blades can be damaged if the squeegee is not raised during storage or transport.
4. Switch off the brush switch (3).
5. Switch off the vacuum motor switch (4).
6. Transport the machine to the location where the recovery tank should be emptied.



7. Empty the recovery tank by removing the drain plug from the drain hose.



WARNING! Use gloves for protection from contact with dangerous solutions.



8. Take the brush off and clean it with water (for brush disassembly please read the section "DISASSEMBLY OF THE BRUSH").

DAILY MAINTENANCE



CLEANING THE RECOVERY TANK

1. Empty the recovery tank by removing the drain plug from the drain hose.




WARNING! Use gloves for protection from contact with dangerous solutions.

2. Lift the cover of the recovery tank.
3. Take off the vacuum plug (1) by rotating it counter-clockwise.
4. Remove the filter and its housing.
5. Rinse the tank with water.



CLEANING THE VACUUM FILTER

1. Lift the cover.
2. Take off the vacuum plug by rotating it counter-clockwise.
3. Remove the filter and its housing.
4. Use water to clean the walls and the bottom of the filter.
5. If necessary, loosen the screws which lock the filter to the housing.
6. Rotate the filter counterclockwise until it is released.
7. Wash all components thoroughly.
8. Reassemble repeating the above operations inversely.




CLEANING THE SQUEEGEE

To obtain the best drying results, keep the squeegee clean.

To clean the squeegee it is necessary to:

1. Remove the hose from the squeegee.
2. Loosen the knobs (1).
3. Clean the inside of the squeegee thoroughly.
4. Clean the squeegee blades thoroughly.
5. Reassemble.




DAILY MAINTENANCE

REPLACING THE SQUEEGEE BLADES

Check the squeegee blades for wear and if necessary, change them.

To replace the squeegee blades:


1. Remove the squeegee hose from its coupling.
2. Take off the pin from the stud bolt.
3. Remove the squeegee from its support.
4. Loosen the wing nuts (1) that lock the rubber blades and take them off.
5. Replace the blades.
6. To reassemble the squeegee, repeat the above operations inversely.




DISASSEMBLY OF THE BRUSH

To remove the brushes:

1. Lift the brush base with the pedal.
2. Make sure the brush switch (1) is OFF.



3. Rotate each brush until they come off the brush plate. The figure shows the rotating direction for releasing the right brush. Rotate in the opposite direction to release the left brush.



WEEKLY MAINTENANCE


CLEANING THE SQUEEGEE HOSE

Weekly or whenever the suction is insufficient, make sure the squeegee hose is not obstructed. To clean:

1. Take off the hose from its coupling on the squeegee.
2. Take off the other end from the recovery tank.
3. Wash the inner part of the hose with a water jet from the tank side.
4. Reassemble.



WARNING! Do not wash the hose that goes from the vacuum motor to the vacuum plug.




SOLUTION TANK CLEANING

1. Remove the cap from the solution tank.
2. Rinse with water.
3. Remove the outer cap (1) and empty the tank.




WARNING! Use gloves for protection from contact with dangerous solutions.



TROUBLE SHOOTING GUIDE

INSUFFICIENT WATER ONTO THE BRUSH

1. Make sure the water valve is open (lever 1).
2. Confirm there is water in the solution tank.



THE MACHINE DOES NOT CLEAN SATISFACTORILY

Check the condition of the brush and replace it if necessary. The brush should be replaced when the bristles reach about 5/8 inch (15mm).

THE SQUEEGEE DOES NOT DRY THE FLOOR WELL

1. Check that the squeegee blades are clean.
2. Adjust the inclination of the squeegee (see “MACHINE PREPARATION” #9).
3. Confirm the vacuum hose is correctly fitted in its housing on the recovery tank.
4. Take off the entire vacuum assembly and clean it.
5. Replace the blades if worn.
6. Check that the vacuum motor switch is on.
7. Check the squeegee height adjustment (see “MACHINE PREPARATION #8).

EXCESSIVE FOAM PRODUCTION

Check that a low foam detergent has been used. If required, add a small quantity of antifoam liquid into the recovery tank.

Remember that more foam is generated when the floor is not very dirty. Use less detergent if this is the case.

REFER TO THE PARTS & SERVICE MANUAL FOR ELECTRICAL SCHEMATICS

WARRANTY POLICY PACIFIC LIMITED WARRANTY

The **Pacific** ScrubMaster 210 has been manufactured, tested and inspected in accordance with specific engineering requirements. This machine is **WARRANTED** to be free from defects in workmanship and materials for periods as follows from the date of purchase.

Ten years parts, One year labor – Polyethylene Components
Five years parts, One year labor – Main Frame
Two years parts, One year labor– Brush Drive Motors
One year parts & labor – All other components unless excluded below

Travel time for warranty repair is authorized for a period of ninety (90) days following the date of sale to the end user, with a maximum of three (3) hours per claim.

This warranty extends to the original user/purchaser and only when used, operated and maintained in accordance with **Pacific** Operating and Maintenance instructions.

This warranty does not apply to certain wear parts and accessories of the machine such as electrical cords, carbon motor brushes, floor brushes, belts, hoses, tools, squeegee blades, etc., nor does it apply to damage or failure caused by improper use, abuse or neglect. Warranty credit or replacement of return parts including motors, pumps, etc., is subject to incoming inspection of those items.

To secure repair under this warranty, the following procedure should be taken:


1. After the expiration of the ninety (90) day travel time warranty period, the customer is responsible for warranty travel payment or the inoperative machine or warranted parts must be delivered to the authorized dealer with shipping and delivery charges prepaid. If unable to locate the Dealer, you may contact **Pacific** at the address listed herein for the location of the nearest **Pacific** repair center or agent or for other instructions pertaining to your warranty difficulty.
2. Upon compliance with the above warranty procedure, all warranted repairs will be completed at no additional charge or cost to the user.
3. Only **Pacific** or its authorized dealers and agents may make no charge warranty repairs on this product. All others do so at their own risk.

This warranty limits **Pacific** liability to the repair of the product and/or warranted parts replacement and does not include incidental or consequential damages arising from the use of a **Pacific** machine whether defective or not.

BATTERY WARRANTY

In addition to the terms above, any original equipment Pacific Battery which becomes unserviceable under normal use within a period of ninety (90) days from date of sale to the original user will be repaired or replaced with one of equal specification at our option, F.O.B. any authorized Pacific Sales or Service Branch, with no charge to user, except transportation costs. After the expiration of the above ninety (90) day period, any battery which fails under normal use will be adjusted to the original user with a new battery of equal specification on a twelve (12) month pro rata basis from the date of purchase. Adjustment will be determined using the then current list price, plus transportation costs. Warranty is rendered null and void if battery is not kept filled to the proper level with **DISTILLED WATER**.

This warranty is in lieu of all other expressed or implied warranties and is extended to the original purchaser/user.



PACIFIC

2259 S. SHERIDAN
MUSKEGON, MICHIGAN 49442-6252

1-800-968-1332

FAX 1-800-863-9536