

# PolyPad Ultra

## Description

The PolyPad Ultra (Diamond Impregnated Pad) is an ideal general use high polishing product. It is a pad made from a blend of polyester and natural fiber that through a unique process, contains a high concentration of abrasive material including diamonds, that are embedded along with a durable resin for long lasting use. It can remove surface scratches and blemishes and bring a polished floor to a bright, high-end finish. It improves the appearance and keeps floors looking new. Use an auto scrubber, burnisher or swing machine.

## Features & Benefits

- Highly efficient and easy to use
- Designed to work on Pacific Floorcares auto scrubbers, high-speed burnishers or swing machines
- Eliminates surface scratches
- Removes scuff marks

NOTE: When installing on equipment, the embedded diamond side is the work surface that contacts the floor.

## Uses

The PolyPad Ultra is ideal for removing surface scratches, scuff marks, and refining a floor. It is recommended that the Ultra pad be used on a Pacific Floorcare auto scrubber, high-speed burnisher or a swing machine. The Pads are used on polished concrete, terrazzo, and VCT.

## Procedures with Pacific Floorcare Auto Scrubber

1. Sweep or dry mop the floor prior to running machines to remove any large objects that may damage equipment.
2. Install PolyPad Ultra on a auto scrubber
3. Move machine forward in a straight line at a slow walking speed
4. Repeat operation until desired surface smoothness or gloss level is reached

## Procedures with Burnisher or Swing Machine

1. Install PolyPad Ultra on a burnisher or swing machine
2. Dust mop floor prior to burnishing
3. Burnish the floor a section at a time
4. Move the machine forward in a straight line at a slow walking speed then pull the machine back over the same line maneuvering it in a tail wagging motion. Repeat step.
5. Continue as in #4 in the adjacent area next to the completed row.
6. For improved uniformity of finish, go over each section a second time using the same technique as in #4, but moving across the first rows at a 90-degree angle. This is called cross-hatching. Repeat #5 and #6 if necessary.
7. When section is finished, move forward and continue the same process until the floor is completely done
8. Repeat operation until desired surface smoothness or gloss level is reached.

## Cleanup

After completing any application using PolyPad Ultra pads, thoroughly rinse and clean each pad. Hang or stand on edge to dry and store appropriately. This will maximize pad life.

# PolyPad Ultra

## Packaging Specifications

Product #	Description	Pack
PLPU141500	PolyPad Ultra Floor Buffer - 14" (356mm) 1500	5 pack
PLPU143000	PolyPad Ultra Floor Buffer - 14" (356mm) 3000	5 pack
PLPU161500	PolyPad Ultra Floor Buffer - 16" (356mm) 1500	5 pack
PLPU163000	PolyPad Ultra Floor Buffer - 16" (356mm) 3000	5 pack
PLPU171500	PolyPad Ultra Floor Buffer - 17" (356mm) 1500	5 pack
PLPU173000	PolyPad Ultra Floor Buffer - 17" (356mm) 3000	5 pack
PLPU201500	PolyPad Ultra Floor Buffer - 20" (356mm) 1500	5 pack
PLPU203000	PolyPad Ultra Floor Buffer - 20" (356mm) 3000	5 pack

## Warning

1. Ensure use in the recommended application and suggested equipment
2. DO NOT allow use by untrained operators
3. Always follow standard safety practices and wear appropriate protective equipment.

## Warranty

This information is based on laboratory testing and results. Because of variations in methods, conditions and equipment, each user must test this product to make a judgment of effectiveness and performance. Product warranty obligation is limited to the refund of purchase price or replacement of product if proven to be defective. Claims must be made in writing and received within one year from date of product sale to original buyer. Sole remedy shall be replacement of product proven defective.

## Product Picture

