Technical Data Sheet

Last updated: 2021 June 14



LUSTR Honing Pads

Description

LUSTR Pads are formulated to provide the user with a beautiful, durable floor and an easy, economical way to maintain a polished concrete floor using a Pacific Floorcare auto scrubber and in-house personnel. The PAC Floor Care System consists of a unique daily maintenance pad and 3-step floor repair pads. The LUSTR Pad has an advanced composite abrasive set on a synthetic fiber pad, which allows the user to maintain a highly refined floor without ongoing stock removal. LUSTR Pads are designed for use under auto scrubbers and swing machines.

Features & Benefits

- Easy to use system for daily maintenance and floor repair
- Highly efficient and economical
- When used with PAC Transform, the LUSTR pads will hone the floor surface to improve the DOI (Distinctness of Image) or clarity of a terrazzo or concrete floor
- The LUSTR honing pads are highly effective at cleaning and preparing the floor surface, greatly reducing the number of passes compared to old style products
- The floor repair pads are as easy to use as 1-2-3

Note: When installing LUSTR pads on equipment, the abrasive side of the pad is the work surface that contacts the floor

Uses

The LUSTR Maintenance Pad System is engineered to work on concrete and terrazzo floors with no topical coating that are either protected by non-film-forming impregnating stain protection agents or not.

Daily Maintenance

- 1. Sweep or dry mop the floor prior to running machines to remove any large objects that may damage equipment.
- 2. Install LUSTR pad on auto scrubber with the abrasive side facing the floor.
- 3. Fill the auto scrubber fill tank with PAC Transform
- 4. Make 4 passes over the floor without recovery at a leisurely pace. Then one pass vacuuming with squeegee

For best results, it is recommended to use PAC Transform bio plant based soap and protectant with Pacific auto scrubbers. It is recommended to always test a small area of the floor prior to restorative work on the whole floor.

Product #	Description	Pack
565902	LUSTR #2 3.5" RING PAD 14"	6 pack
565903	LUSTR #3 3.5" RING PAD 14"	6 pack
565905	LUSTR #2 4.0" RING PAD 20"	6 pack
565906	LUSTR #3 4.0" RING PAD 20"	6 pack

Product Picture





Technical Data Sheet





LUSTR Maintenance System

Warning

- 1. Use the recommended procedures and eauipment
- 2. DO NOT allow use by untrained operators
- 3. Always follow standard safety practices and wear appropriate protective equipment.

Warranty

This information is based on laboratory testing and results. Because of variations in methods, conditions and equipment, each user must test this product to make a judgment of effectiveness and performance. The product warranty obligation is limited to the refund of purchase price or replacement of the product if proven to be defective. Claims must be made in writing and received within one year from the date of product sale to the original buyer. Sole remedy shall be the replacement of the product proven defective.



