

# Ultra Shine Pad

## Description

The Ultra Shine (Diamond Impregnated Pad) is an ideal general use high polishing product. It is a pad made from a blend of polyester and natural fiber that through a unique process, contains a high concentration of abrasive material including diamonds, that are embedded along with a durable resin for long lasting use. It can remove surface scratches and blemishes and bring a polished floor to a bright, high-end finish. It improves the appearance and keeps floors looking new. Use an auto scrubber, burnisher or swing machine.

## Features & Benefits

- Highly efficient and easy to use
- Designed to work on Pacific Floorcares auto scrubbers, high-speed burnishers or swing machines
- Eliminates surface scratches
- Removes scuff marks

NOTE: When installing on equipment, the embedded diamond side is the work surface that contacts the floor.

## Uses

The Ultra Shine pad is ideal for removing surface scratches, scuff marks, and refining a floor. It is recommended that the Ultra Shine pad be used on a Pacific Floorcare auto scrubber with the PAC chemical system. The Pads are used on polished concrete, terrazzo, and VCT.

## Procedures with Pacific Floorcare Auto Scrubber

1. Sweep or dry mop the floor prior to running machines to remove any large objects that may damage equipment.
2. Install Ultra Shine on a auto scrubber
3. Move machine forward in a straight line at a slow walking speed
4. Repeat as instructed for terrazzo/concrete prep or top scrub best practices

## Cleanup

After completing any application using Ultra Shine pads, thoroughly rinse and clean each pad. Hang or stand on edge to dry and store appropriately. This will maximize pad life.

## Packaging Specifications

Product #	Description	Pack
565907	ULTRA SHINE 14"	5 pack
565908	ULTRA SHINE 20"	5 pack

## Warning

1. Ensure use in the recommended application and suggested equipment
2. DO NOT allow use by untrained operators
3. Always follow standard safety practices and wear appropriate protective equipment.

## Warranty

This information is based on laboratory testing and results. Because of variations in methods, conditions and equipment, each user must test this product to make a judgment of effectiveness and performance. Product warranty obligation is limited to the refund of purchase price or replacement of product if proven to be defective. Claims must be made in writing and received within one year from date of product sale to original buyer. Sole remedy shall be replacement of product proven defective.

## Product Picture



**Product Picture**

