BOX EXTRACTORS

PRO SERIES Pro 7R, Pro 10R and Pro 15R

SUPER SERIES Super 7R and Super 10R

INTRODUCTION

OPERATING & MAINTENANCE INSTRUCTIONS

READ THIS BOOK

This operator's book has important information for the use and safe operation of this machine. Read this book carefully before starting the machine. Keep this book and tell all operators to read the book. If you do not follow the instructions, you can cause an injury or damage equipment, furniture or buildings.

For new books write to:

Pacific 2259 S. Sheridan Muskegon, MI 49442-6252

Carefully inspect all components to ensure that there is no concealed freight damage. If such damage is discovered, file a "CONCEALED DAMAGE REPORT" immediately with the delivering carrier.

The contents of this manual are based on the latest product information available at the time of publication. Pacific Steamex reserves the right to make changes or improvements to its machines without notice.

FOR YOUR CONVENIENCE, RECORD THE MACHINE MODEL AND SERIAL NUMBER:

| MODEL | |
|----------------|--|
| SERIAL NUMBER | |
| PART NUMBER | |
| DATE PURCHASED | |

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS MACHINE

WARNING: To reduce the risk of fire, electric shock, or injury:

- 1. You must have training in the operation of this machine before using it.
- 2. Machines can cause an explosion when near flammable materials and vapors. Do not use this machine with or near fuels, grain dust, solvents, thinners, or other flammable materials.
- 3. Do not operate this machine unless it is completely assembled.
- 4. Do not use this unit for dry pick-up of dust or debris. Do not pick up anything that is burning or smoking.
- 5. To prevent electric shock, always remove the electrical plug from the electrical outlet before doing any repairs or maintenance to this machine. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- 6. To prevent injury, always remove the electrical plug from the electrical outlet before leaving the machine.
- 7. Maintenance and repairs must be done by authorized personnel only.
- 8. Do not immerse. To reduce the risk of electrical shock, use only on carpet moistened by the cleaning process. Protect the machine from rain. Keep the machine in a dry building. Always clean the machine with a clean dry cloth.
- 9. Always use a three-wire electrical system connected to the electrical ground. For maximum protection against electrical shock, use a circuit that is protected by a ground fault circuit interrupter. Consult your electrical contractor.
- 10. To prevent damage to the power cord, do not move this machine over the power cord. Always lift the power cord over the machine. Do not pull or carry cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- 11. Make sure all switches are turned off before plugging or unplugging it power cord into/from a wall receptacle.
- 12. Do not use water that is hotter than 60° C (140° F).
- 13. To prevent damage to the solution system components do not store in freezing temperatures without proper maintenance.
- 14. Do not use with damaged cord or plug. If the machine is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- 15. Do not handle the plug or machine with wet hands.
- 16. Do not put any object into openings. Do not use with any opening blocked. Keep free of dust, lint, hair and anything that may reduce the airflow.

Grounding Instructions

This machine must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be inserted into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the machine - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.


This machine is for use on a nominal 120-volt circuit, and has a grounded plug that looks like the plug illustrated in figure A. A temporary adapter that looks like the adapter illustrated in figures B and C may be used to connect this plug to a 2-pole receptacle as shown in figure B if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (figure A) can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw.

NOTE: In Canada, the use of a temporary adapter is not permitted by the Canadian Electrical Code

EXTENSION CORDS

Use only three-wire 14/3 or larger gauge approved extension cords that have three-prong grounding type plugs and three-pole receptacles that accept the appliance's plug. Replace or repair any damaged cords or plugs.

When servicing, refer to authorized person only. Use only identical replacement parts.



OPERATING AND MAINTENANCE PROCEDURES

PRESTART-UP CHECKS

This machine is simple and easy to operate. Very little maintenance and service is required to keep your machine in top operating condition.

The following procedures are recommended to maintain the high level of performance expected from your machine. They are also intended to identify potential safety hazards and problems which could reduce the service life of the machine.

READ BEFORE OPERATING YOUR MACHINE:

- Check power cord, plug and strain relief for worn or damaged insulation. Repair or replace if necessary.
- 2. Make sure the plug is in the **drain hose** and placed in its storage position on the back of the tank.
- Inspect the vacuum head on the wand for any damage. Burrs on the contact surface may snag carpet fibers. Gouges, scratches and chipped areas can reduce vacuum performance.
- 4. Check the inlet strainer located at the bottom of the solution tank for damage or debris. Holes in the screen can allow contaminants to enter the pump resulting in costly repairs. A clogged strainer will reduce pump performance and may cause permanent damage.
- 5. Unscrew the clear round **plastic cover** on top of the recovery (vacuum) tank.
 - a) Inspect the **cover** and **gasket** for damage. Dirt or debris on the gasket or sealing surface of the tank can cause a vacuum leak and reduce vacuum performance.
 - b) The **float assembly** consists of a screen and ball shut off to protect the vacuum motor. To remove it twist the assembly from the white vacuum tube. Then clean the screen of debris. It should be checked periodically for any damage and replaced when necessary.
 - c) Replace the cover, making sure it is securely in place.


OPERATION & MAINTENANCE

The following procedures are intended to describe and detail proper operation of your machine. Failure to follow these recommended procedures can reduce the machine's performance and may result in damage to the machine.

- Vacuum the area to be cleaned. Your machine will do a more thorough job if the loose dirt and debris are removed before the extraction process begins.
- Fill the fresh water tank (lower tank) with hot water and cleaning chemical. Do not use water hotter than 60°C (140°F). Mix in chemicals according to the chemical manufacturer's recommendations. Powdered chemical must be premixed with water before pouring into the solution tank.

- 3. Use of an extension cord is not recommended. However, if one is necessary, use only a 14 gauge or larger cord.
- 4. Connect the wand assembly and hoses to the machine. The solution hose simply inserts into the quick connect located on the front of the machine. The vacuum hose slides over the tube located on the front of the recovery (upper) tank.
- 5. Plug the power cord into a **grounded outlet** of the correct voltage. See Grounding Instructions.
- 6. The control panel contains the following:
 - a) The pump switch should be turned on first. The solution pump is self-priming and completely fills the system. The pump is a demand pump and operates when the valve trigger is activated or when the pressure is below the pump's pressure switch limit.
 - b) **Turn ON the vacuum switch.** You may now begin the cleaning process.
- 7. Depress the **valve trigger** on the wand to allow the solution water to flow.
- 8. Foaming may occur as dirty solution is recovered. Excessive foaming must be counteracted with liquid defoamer (follow the chemical manufacturers directions). Do not allow foam to rise into or near the float assembly in the recovery tank. Use defoamer or empty and flush the recovery tank.
- 9. When finished turn off the vacuum and pump switches, then unplug the power cord from the electrical outlet before doing any cleanup.
- 10. Always drain and clean the recovery tank after each use. Simply pull the plug from the drain hose on the back of the tank and drain. Dispose of the recovered water properly. Then flush out the tank with clean water making sure all deposits and debris are removed. Replace the plug and return the hose to its storage position on the back of the tank.
- 11. After each use **clean the cover, float assembly and gasket.**Do not reinstall the cover until the next use, this will allow the recovery tank to dry out.
- 12. Periodically check and clean the **inlet strainer** in the solution tank. Make sure the strainer is properly in place to protect the pump.
- 13. Wipe the machine down with a damp cloth.

PRO & SUPER



PRO & SUPER PARTS LIST

| ITEM | PART NO. | DESCRIPTION | QTY. | ITEM | PART NO. | DESCRIPTION | QTY. |
|------|----------|----------------------------------|---------|------|----------|---------------------------------|-------|
| 1 | 602012 | Clamp - Hose | 1 | 39 | 3771 | Elbow - Male 1/4 to 3/8, 15R | 1 |
| 2 | 604107 | Hose - Drain Polyvac | 1 | | 211310 | Body - 90 Jet, 7/10R | 1 |
| 3 | S266P1 | Power Cord - 25', 15R only, | 1 | 40 | 202050 | Clamp - Solution Hose | 2 |
| | | (see item 62 for 7/10R cord) | | 41 | S303P | Plate-Pump Mounting, 7/10R | 1 |
| 4 | 962015 | Screw - 10-32 x 3/8 | 1 | | 226670 | Plate - Pump Mounting, 15R | 1 |
| 5 | 608508 | Velcro Strap-Vac Hose Retainer | 1 | 42 | 3785V | Pump - 115 volt | 1 |
| | 203473 | Gasket - Strap , 15R only | 1 | | 3821V | Pump - 230 volt | 1 |
| 6 | 603313 | Fastener - 95707A685 | 1 | 43 | 3765 | Elbow - Male 3/8 to 3/8 | 2 |
| 7 | 920017 | Nut - 10-24 | 1 | 44 | S453P | Clamp - Hose | 2 |
| 8 | W107D | Washer - 3/16 Flat | 1 | 45 | S250P | Hose – 3/8 Push Loc | 3 ft. |
| 9 | 608504 | Stopper - Drain | 1 | 46 | 227750 | Shaft-Wheel, 7/10R | 1 |
| 10 | 602408 | Cord - Stopper Stretch | 1 | | 227770 | Shaft – Wheel, 15R | 1 |
| 11 | 962113 | Screw 10-24 x 1-1/4 S/S PHP | 1 | 47 | W120D | Washer - 7/16 Flat | 2 |
| 12 | A13020 | Relief - Strain | 1 | 48 | 229750 | Wheel - 10 x 1.75 Grey | 2 |
| 13 | 227050 | Panel – Control, 15R | 1 | 49 | S482P | Snap Axle Cap 1/2 | 2 |
| 14 | 911089 | Switch - Rocker 16 amp | 2 | 50 | 204552 | Hinge - Vac Tank | 2 |
| 15 | S519PB | Switch Blanks Black | 1 | 51 | 911104 | Tie - Cable | 1 |
| 16 | W351D | Screw 10-24 x 1/2, 15R only | 4 | 52 | 962122 | Bolt-Tap 1/4-20x3 1/4 , 7/10R | 3 |
| 17 | S799NP1 | Plug - Nickel Plated 7/8 | 1 | | W196D | Screw 1/4 -20 x 4, 15R | 3 |
| 18 | 223403 | Gasket Cover | 1 | 53 | 223370 | Float Assembly | 1 |
| 19 | 222302 | Cover - Cleanout | 1 | | 980630 | Washer-Float Restrictor, Super | 1 |
| 20 | 228651 | Tank Vacuum – 7R | 1 | 54 | 221372 | Baffle, 7/10R | 1 |
| | 228652 | Tank Vacuum - 10R | 1 | | 221371 | Baffle, 15R | 1 |
| | 228673 | Tank Vacuum – 15R | 1 | | 221360 | Extra Baffle, Super 7/10R only | 1 |
| 21 | 962083 | Screw-1/4-20 x 1PHP, 7/10R | 2 | | W213D | Screw, 8-32x3/4FHP (for 221360) | 2 |
| | 962117 | Screw-1/4-20x1-1/2PHP, 15R | 2 | 55 | 930006 | Rivet - Pop 1/8 x 1/2, 15R | 2 |
| 22 | W104D | Washer - 1/4 Flat | 14 | | 930005 | Rivet Alum Pop, 7/10R | 2 |
| 23 | 228550 | Standpipe Assembly, 7R | 1 | 56 | 920616 | Nut - 1/2 NPT | 1 |
| | 228551 | Standpipe Assembly, 10R | 1 | 57 | 225173 | Label - Switch | 1 |
| | 228571 | Standpipe Assembly, 15R | 1 | 58 | 228653 | Tank Solution, 7/10R | 1 |
| 25 | A13012 | Sealing Nut - 1-1/4 | 1 | | 228675 | Tank Solution , 15R | 1 |
| 26 | S446P1 | Gasket - Blower Ring 3/8 | 1 | 59 | D161C | Decal - Defoamer | 1 |
| 27 | A13504 | Vac Motor - 115V, 15R | 1 | 60 | S216P | Clamp - Hose | 1 |
| | 3738 | Vac Motor - 230V, 15R | 1 | 61 | S906A | Brass-Long Nipple, 7/10R | 1 |
| | S322P | Vac Motor-115V, Pro 7/10R | 1 | | 205752 | Nipple-Close 1/4 NPT | 1 |
| | S589P | Vac Motor-230V, Pro 7/10R | 1 | 62 | 908076 | Cord ASM 14/3x25'. 7/10R | 1 |
| | S591P | Vac Motor-115V,Super 7/10R | 2 | 63 | 962015 | Screw 10-32x 3/8 Pan Hd | 5 |
| | S589P | Vac Motor-230V Super 7/10R | 2 | 64 | 920017 | Nut 10-24 ESNA | 2 |
| | 210901 | Carbon Brush for A13504 | 2 | 65 | 227051 | Panel-Control, 7/10R | 1 |
| | 200951 | Carbon Brush for S322P | 2 | 66 | 962121 | Screw 10-24x2 ½ Pan Hd | 2 |
| | 210904 | Carb.Brush for S589P&3738 | 2 | 67 | W343D | Screw 10-24x1 PHP | 1 |
| | S591P1 | Carbon Brush for S591P | 2 | 68 | W106D | Nut 10-24 Hex | 2 |
| 28 | 224160 | Hose | 1.4 ft. | 69 | 980015 | Washer-#10 Ext Tooth | 2 |
| 29 | 203359 | Fitting - Hose Barb 3/8 Hose | 1 | 70 | 508519 | Strain Relief | 1 |
| 30 | S905A | Brass - 90 Degree | 1 | 71 | 708502 | Strain Relief | 1 |
| 31 | 203308 | Quick Connect - 1/4 Female | 1 | 72 | 221350 | Plug Button | 1 |
| 32 | S804N1 | Brass - Hex Head Plug 1/4, 15R | 1 | 73 | 225660 | Mount-Vac Motor, Super | 1 |
| 33 | T4056 | Brass-cplg 1/4 w/nut/washer, 15R | 2 | 74 | 920004 | Nut ¼ -20 Hex, Super | 3 |
| 34 | 962006 | Screw - 1/4-20 x 1/2 | 24 | 75 | 226650 | Plate-Switch Encl. Back, 7/10R | 1 |
| 35 | 980002 | Washer - 1/4 Lock | 15 | 76 | 980022 | Washer #10 Spring Lock, 7/10R | 4 |
| 36 | S130P | Caster | 2 | | 980002 | Washer - 1/4 Lock, 15R | 4 |
| 37 | S626P | Strainer - 3/8 NPT | 1 | 77 | 962030 | Screw 10-32x1/2 Type F PHP | 1 |
| 38 | S479P | Brass-Reducer 3/8x1/4, 15R | 1 | F'' | 502000 | Joseph To GERME Type I I III | + '- |
| - 30 | S372P | Washer:Nylon, 7/10R | 1 | | | | + |
| | | A DEC POD DUMP | | | CODIEC | 1 | |


REPLACEMENT PARTS FOR PUMP

| ITEM | PART NO. | DESCRIPTION | QTY. |
|------|----------|---------------------|------|
| 1 | 204557 | Pump Head | 1 |
| 2 | 3788 | Switch Kit | 1 |
| 3 | 3787 | Valve Kit | 1 |
| 4 | 3786 | Nylon Upper Housing | 1 |
| 5 | 3789 | Diaphragm Kit | 1 |

ACCESSORIES


| ITEM | PART NO. | DESCRIPTION | QTY. |
|------|----------|---------------------------------|------|
| | 219804 | Wand, 12" 2 Jet - See Page 6 | 1 |
| | F213W2 | Solution Hose, 15' - See Page 6 | 1 |
| | F215W | Vacuum Hose, 15' | 1 |

2 JET WAND 219804




| TITEM | | | | | |
|---|---------------|--------|--------------------------------------|------|--|
| 2 W354D Screw 10-24 x 1 PHP MS 4 3 W102D Screw 1/4-20 x 5/8 PHP MS 4 4 W153D2 Screw 10-24 x 3/4 PHP 2 5 S399P Poly Rod 1 6 S124R Grip 1 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 20 S601P </th <th></th> <th></th> <th></th> <th></th> | | | | | |
| 3 W102D Screw 1/4-20 x 5/8 PHP MS 4 4 W153D2 Screw 10-24 x 3/4 PHP 2 5 S399P Poly Rod 1 6 S124R Grip 1 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 20 S601P Wand Tube - Trogamented 1 21 S877P | | W148D | | 2 | |
| 4 W153D2 Screw 10-24 x 3/4 PHP 2 5 S399P Poly Rod 1 6 S124R Grip 1 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877 | | | | - | |
| 5 S399P Poly Rod 1 6 S124R Grip 1 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P <td>3</td> <td></td> <td></td> <td></td> | 3 | | | | |
| 6 S124R Grip 1 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S | - | | | | |
| 7 W131D Screw 1/4-20 x 5" HHCS 1 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S48P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 | | S399P | Poly Rod | | |
| 8 962010 Screw 1/4-20 x 1" HHCS 1 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A< | | | | 1 | |
| 9 213904 Handle Bracket - Half 2 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 7 | W131D | | 1 | |
| 10 214502 Vac Head - Wheelabrated 1 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S98 | 8 | 962010 | Screw 1/4-20 x 1" HHCS | | |
| 11 S973P Cap - Jet 2 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P | 9 | 213904 | Handle Bracket - Half | 2 | |
| 12 W162D Nut 1/4-20 Acorn Zinc 1 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 2108 | 10 | 214502 | Vac Head - Wheelabrated | | |
| 13 962068 Screw 1/4-20 x 5/8 HHCS 1 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 35 T40 | 11 | | Cap - Jet | | |
| 14 505120 Handle - Lever 1 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055< | 12 | W162D | Nut 1/4-20 Acorn Zinc | | |
| 15 218508 Bracket Valve Support 2 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 <td< td=""><td>13</td><td>962068</td><td></td><td></td></td<> | 13 | 962068 | | | |
| 16 203308 Quick Connect 1/4" Female 1 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 <t< td=""><td>14</td><td>505120</td><td>Handle - Lever</td><td>1</td></t<> | 14 | 505120 | Handle - Lever | 1 | |
| 17 S222N Fitting - 1/4 to 1/4 Union 1 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KIT | 15 | 218508 | | 2 | |
| 18 219403 Valve 1 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: | 16 | 203308 | Quick Connect 1/4" Female | 1 | |
| 19 S117P Brass Compression Fitting 2 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 | 17 | S222N | Fitting - 1/4 to 1/4 Union | 1 | |
| 20 S601P Wand Tube - Trogamented 1 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 18 | 219403 | Valve | 1 | |
| 21 S877P2 Jet 11003 Brass 2 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 19 | S117P | Brass Compression Fitting | 2 | |
| 22 S848P Tube - Aluminum 1 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 20 | S601P | Wand Tube - Trogamented | 1 | |
| 23 S904A Brass - Union Tee 1 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | | S877P2 | Jet 11003 Brass | 2 | |
| 24 S222N Fitting - 1/4 to 1/4 Hex 2 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 22 | S848P | Tube - Aluminum | 1 | |
| 25 S905A Brass - 90° Elbow 2 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 23 | S904A | Brass - Union Tee | 1 | |
| 26 S902A Bracket 1 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 24 | S222N | Fitting - 1/4 to 1/4 Hex | 2 | |
| 27 S980P Body - Jet 2 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 25 | S905A | Brass - 90° Elbow | | |
| 28 S280P Strainer - Check Valve 2 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 26 | S902A | Bracket | 1 | |
| 31 210806 Valve Bracket - Right 1 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 27 | S980P | Body - Jet | 2 | |
| 32 210807 Valve Bracket - Left 1 35 T4055 Brass 45° Street Elbow 1 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 28 | S280P | Strainer - Check Valve | 2 | |
| 35 | 31 | 210806 | Valve Bracket - Right | 1 | |
| 36 920011 Nut 1/4-20 Hex w/Nyloc 2 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 32 | 210807 | Valve Bracket - Left | 1 | |
| 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 35 | T4055 | Brass 45° Street Elbow | 1 | |
| 37 W236D Nut 10-24 Hex w/Nyloc 6 SERVICE KITS: 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | | 920011 | Nut 1/4-20 Hex w/Nyloc | 2 | |
| 29 215007 Valve Repair Kit, Includes: Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 37 | W236D | | 6 | |
| Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | SERVICE KITS: | | | | |
| Spring, O-Ring & Washer (212707) 30 212707 Valve Washer - Teflon | 29 | 215007 | Valve Repair Kit, Includes: | | |
| 30 212707 Valve Washer - Teflon | | | | 7) | |
| | 30 | 212707 | | • | |
| | 33 | 215624 | Manifold-2 Jet: Includes Items 23,24 | 1&25 | |


SOLUTION HOSE 15' F213W2



| ITEM | PART NO. | DESCRIPTION | QTY. |
|------|----------|---------------------------|------|
| 1 | S344P1 | Hose 1/4 Gray | 15' |
| 2 | 217501 | Relief - Pressure | 2 |
| 3 | S226P | Ferrule | 2 |
| 4 | S223P | Brass Barb 1/4 to 1/4 MPT | 2 |
| 5 | 203302 | Quick Connect 1/4" Male | 2 |

WIRING DIAGRAMS





WARRANTY POLICY PACIFIC LIMITED WARRANTY

The **Pacific** Pro/Super Carpet Extractor has been manufactured, tested and inspected in accordance with specific engineering requirements and is WARRANTED to be free from defects in workmanship and materials as follows:

Five (5) years parts, One (1) year labor – Polyethylene components. One (1) year parts & labor – All other components unless excluded below.

This warranty extends to the original user/purchaser and only when used, operated and maintained in accordance with **Pacific** Operating and Maintenance instructions.

This warranty does not apply to the following wear parts and accessories of the machine including:

| Part Number | Part Name |
|-------------|-------------------------------|
| 908076 | Cord Assembly, Black (7/10R) |
| 908102 | Cord Assembly, Yellow (7/10R) |
| S266P1 | Cord Assembly, Black (15R) |
| | Cord Assembly, Yellow (15R) |
| 229750 | Wheel |
| S130P | Caster |
| S626P | Strainer |
| 210901 | Carbon Brush for A13504 |
| 200951 | Carbon Brush for S322P |
| 210904 | Carbon Brush for S589P & 3738 |
| S591P1 | Carbon Brush for S591P |
| S877P2 | Jet 11003 |
| S280P | Strainer-Check Valve |

Nor does it apply to damage or failure caused by improper use, abuse or neglect. Warranty credit or replacement of return parts including motors, pumps, etc., is subject to incoming inspection of those items.

To secure repair under this warranty, the following procedure should be taken:

- The inoperative machine or warranted parts must be delivered to the authorized dealer with shipping and delivery charges prepaid. If unable to locate the Dealer, you may contact **Pacific** at the address listed herein for the location of the nearest **Pacific** repair center or agent or for other instructions pertaining to your warranty difficulty.
- Upon compliance with the above warranty procedure, all warranted repairs would be completed at no additional charge or cost to the user.
- Only Pacific or its authorized dealers and agents may make no charge warranty repairs on this product. All others do so at their own risk.

This warranty limits **Pacific** liability to the repair of the product and/or warranted parts replacement and does not include incidental or consequential damages arising from the use of a **Pacific** machine whether defective or not.

This warranty is in lieu of all other expressed or implied warranties and is extended to the original purchaser/user.



2259 Sheridan Muskegon, Michigan 49442 Ph: (800) 968-1332 Fax: (231) 773-1642

www.nextwaveofclean.com

10/01 225658